

Install ipod lead Ford Falcon/Territory

Install Location Tissue Box

- To remove the tissue box in the centre console. Pull up the surround around the shift lever. Remove the screws for the plastic side trim panels and remove the console trim panels.
- Unclip the retaining clip on the tissue box and remove, at the same time disconnect the connector from the back of the cigarette lighter.
- Locate the white 6 pin(5 pins used) auxiliary connector plug behind the fuse box and connect your new lead. (If you are having difficulties finding the white auxiliary plug it is located near the blue 4 pin phone plug
- Run the new cable towards the centre console and above the steering column. Once your cable is in the back of the console unit connect your RCA/3.5mm lead.
- Run the lead out through the tissue box cavity and reassemble centre console.
- Once your lead is connected plug your audio device into the 3.5mm headphone jack and turn it on. Then press the AM button twice on your factory ford radio to active the auxiliary function.

Liability Disclaimer

These instructions are based on carefully documented info and years of research. The author Car Audio New Zealand can not be held accountable for discrepancies due to vehicle options or manufactures variations. Car Audio New Zealand (2006) Ltd can not be held responsible for damage that may occur to the vehicle while using this instruction booklet.