

Commodore VE Key Shell Replacement

1. Find the slot in the back of key below "horn Button" Place a small screw driver in the groove and carefully prise apart the key sections.
2. Remove the top section and find the slot in the bottom of the top section. Use the screw driver to carefully prise apart the front and back sections.
3. Place the remote circuit board and the battery in their correct positions in the new housing being sure to include the silicon pad.
4. Clip new housing back together and clip on to old key bottom.



Liability Disclaimer

These instructions are based on carefully documented info and years of research. The author Car Audio New Zealand can not be held accountable for discrepancies due to vehicle options or manufactures variations. Car Audio New Zealand (2006) Ltd can not be held responsible for damage that may occur to the vehicle while using this instruction booklet.