

Radio Surround AU Falcon

1. Remove factory radio with Ford Radio Removal Tools
<http://www.caraudioonline.co.nz/apps/webstore/products/show/3192774>
2. Attach the side mounting brackets to the radio surround with the screws provided.
3. Mount the head unit into the dash surround from the rear, find correct position and screw to side mounting brackets with the screws supplied with your new radio.
4. Locate vehicles radio wiring harness and connect to your new radio loom using either:

Adapter Loom (Recommended)

If using a vehicle specific adapter loom, connect adapter loom to vehicle radio loom and join other end to new radio loom as indicated by the labels.

Hard Wiring

If Hard Wiring it is recommended that you use an electrical meter to identify wiring. The solder method is recommended to join the wires and it is advised that unused wires are isolated and taped individually.

Connect any other external wiring as required including antenna and test unit.

5. Clip new surround/radio assembly into place in the dash.

Additional Install Items for this Vehicle



Factory Radio Removal Tools

<http://www.caraudioonline.co.nz/apps/webstore/products/show/3192774>



Wiring Adapter Loom

<http://www.caraudioonline.co.nz/apps/webstore/products/show/3192927>

Liability Disclaimer

These instructions are based on carefully documented info and years of research. The author Car Audio New Zealand can not be held accountable for discrepancies due to vehicle options or manufactures variations. Car Audio New Zealand (2006) Ltd can not be held responsible for damage that may occur to the vehicle while using this instruction booklet.

Copyright: Caraudioonline.co.nz