

Holden Commodore Key Shell Replacement

- Remove screws from original shell, and remove key blade.
- Using a flat blade screw driver or knife, gently prise the old key shell apart so as not to damage the module unit
- Remove module unit ensuring the contact rod stays attached to it, being careful not to break the two prongs that hold it into place.
- Insert module unit into bottom key shell until it snaps into the correct position, then put the top shell in place. Ensuring the two lugs at the top of shell are aligned and locked into place.
- Hold key shell together firmly and place your new key blade up into the bottom of the case. Make sure you hold the case firmly together while tightening screws until they are firm, being careful not to strip them.

NOTE: If you are using your old key blade make sure to use the new self tapping screws, and ensure the screws go cleanly through your old key. If the screws bind in the holes you will need to drill them out slightly to allow the screws to pass through into the plastic housing.

Liability Disclaimer

These instructions are based on carefully documented info and years of research. The author Car Audio New Zealand can not be held accountable for discrepancies due to vehicle options or manufactures variations. Car Audio New Zealand (2006) Ltd can not be held responsible for damage that may occur to the vehicle while using this instruction booklet.