

Car Audio Online

Top Quality Car Audio Install Accessories

Holden commodore VT to VX (1997 to Sept 2002) NO363k - stereo fitting kit

- Remove existing stereo if fitted. Removal tools can be found at www.caraudioonline.co.nz/apps/webstore/products/show/3192759
- Remove 2 screws from under ash tray pocket and lift trim from top of centre console around gear shift. Disconnect the harness from power window control switch then remove switches from trim, this will enable easier refitting of this trim.
- Remove 2 screws at sides of ash tray pocket, 2 screws above instruments, pull down the top edge of hinged lower trim panel to expose 3 screws, remove and then remove instrument fascia panel and disconnect 3 wiring harness.
- Remove 4 screws from the sides of stereo aperture, fit double escutcheon over aperture and screw in place. Refit dash fascia.
- Then fit stereo mounting sleeve supplied with your new radio to top hole in escutcheon and lock into place as per instructions supplied with replacement radio. Fit rubber support bush to rear mounting of the new stereo.
- Connect supplied adapter loom to your vehicles radio wiring loom, join the colour coded wires to wiring loom of your new radio. Then connect aerial. Switch on and check all functions then slide into position.
- Fit pocket to lower hole of escutcheon with lock tabs uppermost and foam rubber pad underneath. Reassemble the rest of console.

Liability Disclaimer

These instructions are based on carefully documented info and years of research. The author Car Audio New Zealand can not be held accountable for discrepancies due to vehicle options or manufactures variations. Car Audio New Zealand (2006) Ltd can not be held responsible for damage that may occur to the vehicle while using this instruction booklet.

Copyright: Caraudioonline.co.nz