

Car Audio Online

Top Quality Car Audio Install Accessories

Gliderol TM 305-C

Must have green Circuit Board

1. Carefully remove cover from control box.
2. Press the receiver button located at the top left of the receiver board of the control box.
3. Once pressed a red light will illuminate
4. Press button "A" on your new remote and hold until red light turns off.



Original



Replacement



Liability Disclaimer

These instructions are based on carefully documented info and years of research. The author Car Audio New Zealand can not be held accountable for discrepancies due to vehicle options or manufactures variations. Car Audio New Zealand (2006) Ltd can not be held responsible for damage that may occur to the vehicle while using this instruction booklet.

Copyright: Caraudioonline.co.nz