

BMW Series 3 1999 to 2005 & 2006 Coupe Radio Surround Install Instructions

1. Disconnect the negative Battery Terminal
2. Unclip and remove the trim from above the glove box. Unclip and remove the trim from above the radio.
3. Remove the two screws from the factory radio and remove after disconnecting the wiring
4. Locate vehicles radio wiring harness and connect to your new radio loom using either
Adapter Loom (Recommended)
If using a vehicle specific adapter loom, connect adapter loom to vehicle radio loom and join other end to new radio loom as indicated by the labels.

Hard Wiring

If Hard Wiring it is recommended that you use an electrical meter to identify wiring. The solder method is recommended to join the wires and it is advised that unused wires are isolated and taped individually.

Connect any other external wiring as required and also antenna. (it is possible you will need an antenna adapter as shown below)

5. Mount the Din Mounting Sleeve supplied with your new radio into the radio opening, as per instructions supplied with your new radio. Slide your new radio into the Din Mounting Sleeve
6. After you have tested your new unit screw the new radio surround to the dash using screws removed in step 3.
7. Replace the trim panels in reverse order.

Additional Install Items

<http://www.caraudioonline.co.nz/apps/webstore/products/show/3210113>



Adapter Loom Round Pin



Aerial Adapter > 2001



Aerial Adapter 2001>

Liability Disclaimer

These instructions are based on carefully documented info and years of research. The author Car Audio New Zealand can not be held accountable for discrepancies due to vehicle options or manufactures variations. Car Audio New Zealand (2006) Ltd can not be held responsible for damage that may occur to the vehicle while using this instruction booklet.