

BMW Series 5 1997 to 2003 X5 2000 to 2006 Radio Surround Install Instructions

1. Disconnect the negative Battery Terminal
2. Remove volume knob. Using a torx head screw driver turn the release lever under the volume shaft 90° and then pull out the bottom unit.
3. Loosen the two hex screws next to the radio guides and remove the top radio unit.
4. Clip your new radio surround into position in the dash.
5. Locate vehicles radio wiring harness and connect to your new radio loom using either
Adapter Loom (Recommended)
If using a vehicle specific adapter loom, connect adapter loom to vehicle radio loom and join other end to new radio loom as indicated by the labels.

Hard Wiring

If Hard Wiring it is recommended that you use an electrical meter to identify wiring. The solder method is recommended to join the wires and it is advised that unused wires are isolated and taped individually.

Connect any other external wiring as required and also antenna. (it is possible you will need an antenna adapter as shown below)

6. Mount the Din Mounting Sleeve supplied with your new radio into the radio opening and bend out locking tabs as per instructions supplied with your new radio. Slide your new radio into the Din Mounting Sleeve.

Additional Install Items

<http://www.caraudioonline.co.nz/apps/webstore/products/show/3284262>



Adapter Loom 17 Round Pin
or 16 Flat Pin



Aerial Adapter > 2001



Aerial Adapter 2001 >

Liability Disclaimer

These instructions are based on carefully documented info and years of research. The author Car Audio New Zealand can not be held accountable for discrepancies due to vehicle options or manufactures variations. Car Audio New Zealand (2006) Ltd can not be held responsible for damage that may occur to the vehicle while using this instruction booklet.