

Coding Instructions

Tiltamatic, DoorMate and B& D

- Hold your old original remote in one hand and your new remote in the other. Hold them side by side close enough to touch.
- Push and hold the button you will like to copy on your new remote. Once blue LED flashes push and hold the button on the remote you are copying from. Once the new copy remote has received and copied the code you will see the blue LED flash again.
- If you are having trouble getting the new remote to receive the code from the original slowly move the new around to the top/back and other side of the old remote.
- Release both the button on the original remote and the new remote. Repeat for the other buttons that need to be copied.



Replaces the following Tilt-a-matic, Door Mate and B & D Remotes



Liability Disclaimer

These instructions are based on carefully documented info and years of research. The author Car Audio New Zealand can not be held accountable for discrepancies due to vehicle options or manufactures variations. Car Audio New Zealand (2006) Ltd can not be held responsible for damage that may occur to the vehicle while using this instruction booklet.