

Falcon and Territory Remote Coding

1. Switch the ignition from the “off” to the “acc” position
2. Press the rear window demister button 3 times within 5 seconds. The doors locks will cycle to indicate the the system is in the training mode.
3. Press any button on the remote to be trained. The door locks will cycle to indicate that the remote has been trained. (The first remote to be trained will result in one door lock cycle, the second remote will result in two door lock cycles)
4. Repeat step 3 for all other remotes to be trained
5. Turn the ignition to “off” The door locks will cycle to indicate that the training mode has been exited.

Note: Common problems for vehicles not entering programming mode are, the interior light circuit not working correctly(faulty Bulb or door pin), doors or boot not being shut when programming or an AUX device such as the radio being turned on.

Liability Disclaimer

These instructions are based on carefully documented info and years of research. The author Car Audio New Zealand can not be held accountable for discrepancies due to vehicle options or manufactures variations. Car Audio New Zealand (2006) Ltd can not be held responsible for damage that may occur to the vehicle while using this instruction booklet.